

# PCM MODIFYING

## 2015+ Model Years Only

✓ **Note: The PCM will have to be sent in to be modified. Failure to do so will result in the PCM from being able to be tuned.**

- 1 Disconnect the negative battery cable.
- 2 Ensure there is no battery power to the vehicle.
- 3 Disconnect the connectors on the PCM. Remove the bolts securing the PCM and remove it from the vehicle.
- 4 Diablosport will need to be contacted (561-908-0040) to send in the PCM to be modified.
- 5 A PCM modifying sheet is included for mailing in your PCM to Diablosport. Fill out the sheet with all of the listed information this will ensure the PCM is modified correctly and is returned to the correct address.
- 6 Once the PCM is returned, re-install it into the vehicle. Reconnect all connections including the battery.

**For 2005-16 Automotive Tuning Proceed To Page: 7**

**For Truck ,Jeep, and 2017 Automotive Tuning Proceed To Page: 9**